

---

**RAUKANTEX ABS**  
Technical information

---

---

# RAUKANTEX ABS

## Technical information

---

### Materials for edgeband processing

REHAU uses the thermoplastic materials PVC (Polyvinyl Chloride), ABS (Acrylonitrile-Butadiene-Styrene) PP (Polypropylene) and PMMA (Polymethylmethacrylate) in its extensive RAUKANTEX edgeband product range. Thermoplastic materials are polymer materials that can be melted and therefore thermoformed, processed and recycled.

### ABS as an edgeband material

ABS (Acrylonitrile-Butadiene-Styrene) is a widely-used thermoplastic material with excellent material and processing properties. The furniture industry has been using it since the 1980s. In particular the high impact strength and good mechanical and thermal properties make ABS a widely-used material in the furniture industry, which meets the fire protection class B2 to DIN 4102.

### ABS material (Acrylonitrile-Butadiene-Styrene)

ABS plastics are thermoplastics that, due to their chemical composition, belong to the high-impact polystyrene group. As a result of the specific combination of the individual monomers a high-impact, mechanically resistant, high-quality, cadmium and lead-free polymer material is created. In addition to this, the REHAU material formulation demonstrates improved heat resistance, ageing resistance, mechanical stability, chemical resistance and surface gloss compared to impact resistant polystyrene.

### 1. Areas of application

The spectrum of applications for the RAUKANTEX ABS is almost limitless: From the office to the bathroom and kitchen, exhibition stand construction and shop fitting, the living area through to commercial construction. The processing-friendly RAUKANTEX ABS formulation affords both smooth continuous processing and easy application to free-form parts.

### 2. Recycling/disposal

Taking into account legal stipulations, RAUKANTEX ABS edgeband can be burned in units approved to do so, without any problems. No by-products that are harmful to health are produced if it is burned in the correct way. Even wood based boards with ABS edgeband applied can be disposed of easily.

### 3. Characteristics/Properties

The properties of the RAUKANTEX ABS edgeband fulfil the requirements of the furniture industry. The ABS edgeband possesses the following properties:



#### Shore hardness D

RAUKANTEX ABS edgebands achieve good results with a Shore hardness D of 70 +/- 4 to EN ISO 868.



#### Heat resistance \ Vicat softening temperature

With a value of approx. 90°C to ISO 306 / B50 RAUKANTEX ABS edgebands are especially suited for use in the furniture industry.



#### Abrasion resistance

The surface of RAUKANTEX decorative edgeband in ABS is protected against scratches with a UV lacquer, whereby the decorative designs demonstrate excellent scratch and abrasion resistance. In case of a strong contact pressure in connection with rubbing, slight staining from intensive or dark colour shades cannot be excluded for technical reasons..



#### Chemical resistance

RAUKANTEX ABS edgebands are chemically resistant to all household cleaners to DIN 68861 Part 1 and fulfil stress group 1B.



#### Light fastness

RAUKANTEX ABS edgebands are regularly tested in an accredited laboratory in line with EN ISO 4892-2 regarding light fastness. With a light fastness of  $\geq 6$  on the blue scale these edgebands are ideally suited for interior application. An analysis of the colour deviation is then carried out along the lines of EN ISO 105-A02 using the grey scale.



#### Cleaning

Special plastic cleaners are recommended for cleaning RAUKANTEX ABS edgebands. The use of substances containing solvents and alcohol is strongly advised against.

	PVC	ABS	PP	PMMA
<b>Light fastness</b> In accordance with EN ISO 4892-2	≥ 6	≥ 6	≥ 6	≥ 6
<b>Shrinkage</b> Edgeband 3 mm 1h at 90 °C	≤ 1.7 %	≤ 1.7 %	≤ 0.2 %	≤ 1.0 %
<b>Vicat softening point</b> to ISO 306, Method B50	approx. 67 °C	approx. 95 °C	approx. 100 °C	approx. 80 °C
<b>Hardness Shore D</b> to DIN EN ISO 7619-1	79 ± 4	70 ± 4	75 ± 4	80 ± 3
<b>Chemical resistance</b> to DIN 68861-1	Very good - 1B	Good - 1B	Very good - 1B	Good – 1B*
<b>Thermal conductivity</b> to DIN 52612	0.16 W/m K	0.18 W/m K	0.41 W/m K	0.18 W/m K

\* Limited resistance against solvents and alcohols.

#### 4. Storage

If stored properly, RAUKANTEX edgebands can be stored for min. 12 months. For edgebands older than 12 months, however, a processing trial should always be carried out prior to series processing.

Recommended storage conditions are:

- Room temperature (approx. 18 °C to 25 °C)
- Dry
- Clean
- No vapours containing solvents
- Protected from light

#### 5. Standard tolerances

RAUKANTEX pure ABS edgebands are subjected to regular quality checks in order to guarantee the high quality of every production run. In addition to this we are constantly working to improve the raw material properties.

The production tolerances for edgebands are defined exactly and are checked throughout every production run.

The standard tolerances for RAUKANTEX edgebands can be obtained from your contact person on request or you can find them on the internet.

#### 6. Processing

##### Manual processing


It is possible to process RAUKANTEX pure ABS edgeband manually using edge clamps. Special PVA adhesives, solvent-based adhesives and cartridge adhesives (e.g. Kantol) can be used for glueing by hand. Processing tests should be carried out in order to determine the suitability of the technical application in each case.

##### Machine processing

RAUKANTEX pure ABS edgebands can be processed on all edgebanders (straight line edgebanders and BAZ (processing centres) using hot melt adhesive. The various processing steps such as glueing, capping, milling, scraping and also reworking with buffing wheels and hot air are possible without any problems.

To achieve a high-quality and durable edgeband application several important processing parameters have to be considered which depend on the components used (edgeband, glue and boards), the edgebander and the ambient temperature. In order to identify the ideal conditions it is recommended that trials are carried out and that the reference values specified by the relevant manufacturer are observed.

#### Process steps of machine processing



## Adhesive

RAUKANTEX ABS edgebands can be processed with all commercially available hot melt adhesives (EVA, PA, APAO and PUR). These highly heat-stable adhesives together with the RAUKANTEX ABS edgebands guarantee a secure bond. For products exposed to high ambient temperatures (e.g. containerised transportation) hot melt adhesives with a high softening temperature are recommended. Due to the high heat resistance of the ABS edgebands (approx. 90 °C) material softening during general applications does not occur.

During adhesion ensure that the adhesive is applied consistently and that the glue spreading rollers do not extend too far into the line of the board.

The processing temperature of the adhesive varies depending on the type of adhesive. Be aware that the thermostats in melt containers are often inaccurate and the temperature of the applicator roller can vary by up to 30 °C.

## Processing temperature

To achieve the best possible results during edgeband application the boards and edgebands should be processed at a room temperature of > 18 °C otherwise the adhesive sets too quickly. Draughts should also be avoided for this reason.

## Wood humidity

The optimum wood humidity of the board material is between 7 and 10%.

## Processing feed

RAUKANTEX ABS edgebands are suitable for the common processing rate of feed both in the commercial as well as industrial sector.

## Adhesive application

To achieve ideal processing the information provided by the adhesive manufacturer should be observed. The adhesive application should be calculated in such a way that small beads of adhesive are pressed out from the edges of the freshly glued edgebands and the voids between the substrate particles are filled. The amount of adhesive in each case depends on the type of board, the substrate density, the edgeband material, the processing feed and the type of adhesive.

## Milling

If possible use a 3 to 6 tooth milling tool with a diameter of 70 mm and 12.000 to 18.000 RPM counter to board travel (up-cutting). Inappropriate speeds or blunt tools can damage the edgebands. If a smear effect occurs the speed of the milling tool or the number of teeth should be reduced. The quality of the milled surface (e.g. chatter marks) can be improved by adjusting the feed, speed and number of blades.

## Scraping

The ABS material tends to become slightly lighter after scraping, therefore the chip produced by the scraper should be a maximum of 0.1-0.15 mm. To obtain a high-quality surface after scraping, aim for a milling finish with as few chatter marks as possible.

## Buffing

RAUKANTEX ABS edgebands can be buffed to generate a high quality edge radius. Colour deviation (stress whitening) caused during scraping of the edge radius can be eliminated to achieve a consistent finish by using a down-cutting buffing wheel set-up i.e. the wheels rotate with the travel of the board. Additionally, if release and cleaning agents are used during board processing, the buffing wheels will remove any unwanted glue residue.

## Processing with invisible joint technology

RAUKANTEX pro/plus ABS edgebands are designed to be processed on edgebanding machines working with CO<sub>2</sub> or diode laser, hot air or NIR processes. Please refer to the technical information for zero-joint edgebands regarding special information.

Processing properties	PVC	ABS	PP	PMMA
<b>Capping</b>	Good	Good	Good	Good
<b>Milling direction</b>	<b>Straight line processing</b> Up-cutting	Up-cutting	Up-cutting	Up-cutting
	<b>BAZ</b> Down-cutting/Upcutting	Down-cutting/Upcutting	Down-cutting/Upcutting	Down-cutting/Upcutting
<b>Pre-milling</b>	Good	Good	Good	Good
<b>Radius milling</b>	Good	Good	Good	Good
<b>Contour milling</b>	Good	Good	Good	Good
<b>Scraping</b>	Very good	Good	Good	Good
<b>Buffing</b>	Very good	Good	Good	Good
<b>Down-cutting</b>	Standard market hotmelts	Standard market hotmelts	Standard market hotmelts	Standard market hotmelts
<b>Polishability</b>	Good	Good	Average	Very good
<b>Stress whitening tendency</b>	Low	Average	Low	Low
<b>Processing centre capability</b>	Very good	Good	Very good	Superior

## 7. Frequently asked questions

Problem	Diagnosis of the problem
1 The edgeband can easily be removed by hand. The hot melt adhesive remains on the chipboard (straight line) or on the edgeband (processing centre). It is possible to see the marking made by the adhesive application roller.	<ul style="list-style-type: none"> <li>- Adhesive application not sufficient</li> <li>- Room or edgeband temperature too low</li> <li>- Draughty environment</li> <li>- Hot melt adhesive temperature too low</li> <li>- Processing feed too low</li> <li>- Contact pressure of the pressure roller too low</li> </ul>
2 The edgeband can easily be removed by hand. Hot melt adhesive remains on the chipboard (straight line). The hot melt adhesive surface is completely smooth.	<ul style="list-style-type: none"> <li>- Board and/or edgeband is too cold.</li> <li>- Check hot melt adhesive type</li> <li>- Check primer application</li> </ul>
3a Glue joint is not sealed (straight line)	<ul style="list-style-type: none"> <li>- Adhesive too cold</li> <li>- Adhesive application too low</li> <li>- Contact pressure too low</li> <li>- Edgebands have incorrect pre-tensioning</li> <li>- Scoring saw alignment is incorrect</li> <li>- Contact between the adhesive application roller and board</li> <li>- Debris not removed from board cross-section</li> </ul>
3b Glue joint is not sealed (straight line)	<ul style="list-style-type: none"> <li>- Contact pressure too low</li> <li>- Curvature of the edgeband too high</li> <li><b>Measure/Proposal:</b> Application of external heat</li> <li>- Check hot melt adhesive type (insufficient heat adhesion)</li> <li>- Edgeband pre-tensioning is incorrect</li> <li>- Adhesive does not set in good time</li> <li><b>Measure/Proposal:</b> Reduce the adhesive temperature</li> </ul>
4 The glued edgeband does not show sufficient adhesion at the start	<ul style="list-style-type: none"> <li>- Adhesive application roller is not positioned correctly</li> <li>- Increase the amount of adhesive</li> </ul>
5 Milling lines are visible	<ul style="list-style-type: none"> <li>- Feed too high</li> <li>- Number of blades too low</li> <li>- Speed too low</li> <li><b>Measure/Proposal:</b> Rework with scraper and polishing station</li> </ul>
6 Edgeband splits during the milling process	<ul style="list-style-type: none"> <li>- Edgeband vibrates during the milling process</li> <li>- Adhesion insufficient</li> <li>- Edgeband projection too large</li> <li><b>Measure/Proposal:</b> Check adhesion parameters</li> <li><b>Measure/Proposal:</b> Check adhesive type</li> </ul>
7 Stress whitening of the edgeband in the milled area, principally after scraping	<ul style="list-style-type: none"> <li>- Chip of the scraper too thick</li> <li>- Scraper set up incorrectly</li> <li><b>Measure/Proposal:</b> Blunting of the scrapers edge</li> <li><b>Measure/Proposal:</b> Rework with buffing station</li> </ul>
8 Stress whitening occurs during processing centre processing	<ul style="list-style-type: none"> <li>- Micro-cracks occur in the radius area due to processing temperature being too cold</li> <li><b>Measure/Proposal:</b> Application of external heat in the radius area</li> <li><b>Measure/Proposal:</b> Use of larger radiuses or thinner edgebands</li> </ul>

This document is protected by copyright. All rights based on this are reserved. No part of this publication may be translated, reproduced or transmitted in any form or by any similar means, electronic or mechanical, photocopying, recording or otherwise, or stored in a data retrieval system.

Our verbal and written advice with regard to usage is based on years of experience and standardised assumptions and is provided to the best of our knowledge. The intended use of REHAU products is described comprehensively in the technical product information. The latest version can be viewed at [www.rehau.com/IT](http://www.rehau.com/IT). We have no control over the application, use or processing of the products. Responsibility for these activities therefore remains entirely with the respective user/processor. Where claims for liability nonetheless arise, they shall be governed exclusively according to our terms and conditions, available at [www.rehau.com/conditions](http://www.rehau.com/conditions), insofar as nothing else has been agreed upon with REHAU in writing. This shall also apply for all warranty claims, with the warranty applying to the consistent quality of our products in accordance with our specifications. Subject to technical changes.

#### REHAU SALES OFFICES

AE: Middle East, +971 4 8835677, [dubai@rehau.com](mailto:dubai@rehau.com) AR: Buenos Aires, +54 11 48986000, [buenosaires@rehau.com](mailto:buenosaires@rehau.com) AT: Linz, +43 732 3816100, [linz@rehau.com](mailto:linz@rehau.com) Wien, +43 2236 24684, [wien@rehau.com](mailto:wien@rehau.com) AU: Adelaide, +61 8 28990031, [adelaide@rehau.com](mailto:adelaide@rehau.com) Brisbane, +61 7 55271833, [brisbane@rehau.com](mailto:brisbane@rehau.com) Melbourne, +61 3 95875544, [melbourne@rehau.com](mailto:melbourne@rehau.com) Perth, +61 8 94564311, [perth@rehau.com](mailto:perth@rehau.com) Sydney, +61 2 87414500, [sydney@rehau.com](mailto:sydney@rehau.com) AZ: Baku, +99 412 5110792, [baku@rehau.com](mailto:baku@rehau.com) BA: Sarajevo, +387 33 475500, [sarajevo@rehau.com](mailto:sarajevo@rehau.com) BE: Bruxelles, +32 16 399911, [bruxelles@rehau.com](mailto:bruxelles@rehau.com) BG: Sofia, +359 2 8920471, [sofia@rehau.com](mailto:sofia@rehau.com) BR: Arapongas, +55 43 31522004, [arapongas@rehau.com](mailto:arapongas@rehau.com) Belo Horizonte, +55 31 33097737, [belohorizonte@rehau.com](mailto:belohorizonte@rehau.com) Caxias do Sul, +55 54 32146606, [caxias@rehau.com](mailto:caxias@rehau.com) Mirassol, +55 17 32535190, [mirassol@rehau.com](mailto:mirassol@rehau.com) Recife, +55 81 32028100, [recife@rehau.com](mailto:recife@rehau.com) BY: Minsk, +375 17 2450209, [minsk@rehau.com](mailto:minsk@rehau.com) CA: Moncton, +1 506 5382346, [moncton@rehau.com](mailto:moncton@rehau.com) Montreal, +1 514 9050345, [montreal@rehau.com](mailto:montreal@rehau.com) Toronto, +1 905 3353284, [toronto@rehau.com](mailto:toronto@rehau.com) Vancouver, +1 604 6264666, [vancouver@rehau.com](mailto:vancouver@rehau.com) CH: Bern, +41 31 720120, [bern@rehau.com](mailto:bern@rehau.com) Vevey, +41 21 9482636, [vevey@rehau.com](mailto:vevey@rehau.com) Zuerich, +41 44 8397979, [zuerich@rehau.com](mailto:zuerich@rehau.com) CN: Guangzhou, +86 20 87760343, [guangzhou@rehau.com](mailto:guangzhou@rehau.com) Beijing, +86 10 64282956, [beijing@rehau.com](mailto:beijing@rehau.com) Shanghai, +86 21 63551155, [shanghai@rehau.com](mailto:shanghai@rehau.com) Chengdu, +86 28 86283218, [chengdu@rehau.com](mailto:chengdu@rehau.com) Xian, +86 29 68597000, [xian@rehau.com](mailto:xian@rehau.com) Shenyang, +86 24 22876807, [shenyang@rehau.com](mailto:shenyang@rehau.com) CO: Bogota, +57 1 898 528687, [bogota@rehau.com](mailto:bogota@rehau.com) CZ: Praha, +420 272 190111, [paha@rehau.com](mailto:paha@rehau.com) DE: Berlin, +49 30 667660, [berlin@rehau.com](mailto:berlin@rehau.com) Bielefeld, +49 521 208400, [bielefeld@rehau.com](mailto:bielefeld@rehau.com) Bochum, +49 234 689030, [bochum@rehau.com](mailto:bochum@rehau.com) Frankfurt, +49 6074 40900, [frankfurt@rehau.com](mailto:frankfurt@rehau.com) Hamburg, +49 40 733402100, [hamburg@rehau.com](mailto:hamburg@rehau.com) Leipzig, +49 34292 820, [leipzig@rehau.com](mailto:leipzig@rehau.com) München, +49 8102 860, [muenchen@rehau.com](mailto:muenchen@rehau.com) Nürnberg, +49 9131 934080, [nuernberg@rehau.com](mailto:nuernberg@rehau.com) Stuttgart, +49 7159 16010, [stuttgart@rehau.com](mailto:stuttgart@rehau.com) DK: København, +45 46 773700, [kobenhavn@rehau.com](mailto:kobenhavn@rehau.com) EE: Tallinn, +372 6025850, [tallinn@rehau.com](mailto:tallinn@rehau.com) ES: Barcelona, +34 93 6353500, [barcelona@rehau.com](mailto:barcelona@rehau.com) Bilbao, +34 94 4538636, [bilbao@rehau.com](mailto:bilbao@rehau.com) Madrid, +34 91 6839425, [madrid@rehau.com](mailto:madrid@rehau.com) FI: Helsinki, +358 9 87709900, [helsinki@rehau.com](mailto:helsinki@rehau.com) FR: Lyon, +33 4 72026300, [lyon@rehau.com](mailto:lyon@rehau.com) Metz, +33 6 8500, [metz@rehau.com](mailto:metz@rehau.com) Paris, +33 1 34836450, [paris@rehau.com](mailto:paris@rehau.com) GB: Glasgow, +44 1698 503700, [glasgow@rehau.com](mailto:glasgow@rehau.com) Manchester, +44 161 7777400, [manchester@rehau.com](mailto:manchester@rehau.com) Slough, +44 1753 588500, [slough@rehau.com](mailto:slough@rehau.com) Ross on Wye, +44 1989 762643, [rowy@rehau.com](mailto:rowy@rehau.com) London, +44 207 3078590, [london@rehau.com](mailto:london@rehau.com) GE: Tbilisi, +995 32 559909, [tbilisi@rehau.com](mailto:tbilisi@rehau.com) GR: Athens, +30 21 06682500, [athens@rehau.com](mailto:athens@rehau.com) Thessaloniki, +30 2310 633301, [thessaloniki@rehau.com](mailto:thessaloniki@rehau.com) HK: Hongkong, +8 52 28987080, [hongkong@rehau.com](mailto:hongkong@rehau.com) HR: Zagreb, +385 1 3444711, [zagreb@rehau.com](mailto:zagreb@rehau.com) HU: Budapest, +36 23 530700, [budapest@rehau.com](mailto:budapest@rehau.com) ID: Jakarta, +62 21 45871030, [jakarta@rehau.com](mailto:jakarta@rehau.com) IE: Dublin, +353 1 8165020, [dublin@rehau.com](mailto:dublin@rehau.com) IN: Mumbai, +91 22 61485858, [mumbai@rehau.com](mailto:mumbai@rehau.com) New Delhi, +91 11 45044700, [newdelhi@rehau.com](mailto:newdelhi@rehau.com) Bangalore, +91 80 2222001314, [bangalore@rehau.com](mailto:bangalore@rehau.com) IT: Pesaro, +39 0721 200611, [pesaro@rehau.com](mailto:pesaro@rehau.com) Roma, +39 06 90061311, [roma@rehau.com](mailto:roma@rehau.com) Treviso, +39 0422 726511, [treviso@rehau.com](mailto:treviso@rehau.com) JP: Tokyo, +81 3 57962102, [tokyo@rehau.com](mailto:tokyo@rehau.com) KR: Seoul, +82 2 50116566, [seoul@rehau.com](mailto:seoul@rehau.com) KZ: Almaty, +7 727 3941301, [almaty@rehau.com](mailto:almaty@rehau.com) LT: Vilnius, +370 5 2461400, [vilnius@rehau.com](mailto:vilnius@rehau.com) LV: Riga, +371 6 7609080, [riga@rehau.com](mailto:riga@rehau.com) MA: Casablanca, +212 522250593, [casablanca@rehau.com](mailto:casablanca@rehau.com) MK: Skopje, +389 2 2402, [skopje@rehau.com](mailto:skopje@rehau.com) MX: Celaya, +52 461 6188000, [celaya@rehau.com](mailto:celaya@rehau.com) Monterrey, +52 81 81210130, [monterrey@rehau.com](mailto:monterrey@rehau.com) NL: Nijkerk, +31 33 2479911, [nijkerk@rehau.com](mailto:nijkerk@rehau.com) NO: Oslo, +47 2 2514150, [oslo@rehau.com](mailto:oslo@rehau.com) NZ: Auckland, +64 9 2722264, [auckland@rehau.com](mailto:auckland@rehau.com) PE: Lima, +51 1 2261713, [lima@rehau.com](mailto:lima@rehau.com) PL: Poznań, +48 61 8498400, [poznan@rehau.com](mailto:poznan@rehau.com) PT: Lisboa, +351 21 8987050, [lisboa@rehau.com](mailto:lisboa@rehau.com) Oporto, +351 22 94464, [oporto@rehau.com](mailto:oporto@rehau.com) QA: Qatar, +974 44101608, [qatar@rehau.com](mailto:qatar@rehau.com) RO: Bacău, +40 234 512066, [bacau@rehau.com](mailto:bacau@rehau.com) Bucuresti, +40 21 2665180, [bucuresti@rehau.com](mailto:bucuresti@rehau.com) Cluj Napoca, +40 264 415211, [clujnapoca@rehau.com](mailto:clujnapoca@rehau.com) RS: Beograd, +381 11 3770301, [beograd@rehau.com](mailto:beograd@rehau.com) RU: Chabarowsk, +7 4212 411218, [chabarowsk@rehau.com](mailto:chabarowsk@rehau.com) Jekaterinburg, +7 343 2535305, [jekatarinburg@rehau.com](mailto:jekatarinburg@rehau.com) Krasnodar, +7 861 2103636, [krasnodar@rehau.com](mailto:krasnodar@rehau.com) Nishnij Nowgorod, +7 831 4678078, [nishnijnowgorod@rehau.com](mailto:nishnijnowgorod@rehau.com) Novosibirsk, +7 3832 000353, [novosibirsk@rehau.com](mailto:novosibirsk@rehau.com) Rostow am Don, +7 8632 978444, [rostow@rehau.com](mailto:rostow@rehau.com) Samara, +7 8462 698058, [samara@rehau.com](mailto:samara@rehau.com) St. Petersburg, +7 812 3266207, [stpetersburg@rehau.com](mailto:stpetersburg@rehau.com) Woronesch, +7 4732 611858, [woronesch@rehau.com](mailto:woronesch@rehau.com) SE: Örebro, +46 19 206400, [orebro@rehau.com](mailto:orebro@rehau.com) SG: Singapore, +65 63926006, [singapore@rehau.com](mailto:singapore@rehau.com) SK: Bratislava, +421 2 68209110, [bratislava@rehau.com](mailto:bratislava@rehau.com) TH: Bangkok, +66 27635100, [bangkok@rehau.com](mailto:bangkok@rehau.com) TW: Taipei, +886 2 87803899, [taipei@rehau.com](mailto:taipei@rehau.com) UA: Dnepropetrowsk, +380 56 3705028, [dnepropetrowsk@rehau.com](mailto:dnepropetrowsk@rehau.com) Kiev, +380 44 4677710, [kiev@rehau.com](mailto:kiev@rehau.com) Odessa, +380 48 7800708, [odessa@rehau.com](mailto:odessa@rehau.com) Lviv, +380 32 2958920, [lviv@rehau.com](mailto:lviv@rehau.com) US: Detroit, +1 248 8489100, [detroit@rehau.com](mailto:detroit@rehau.com) Grand Rapids, +1 616 2856867, [grandrapids@rehau.com](mailto:grandrapids@rehau.com) Los Angeles, +1 951 5499017, [losangeles@rehau.com](mailto:losangeles@rehau.com) Minneapolis, +1 612 2530576, [minneapolis@rehau.com](mailto:minneapolis@rehau.com) VN: Ho Chi Minh City, +84 8 38233030, [sales.vietnam@rehau.com](mailto:sales.vietnam@rehau.com) ZA: Durban, +27 31 7657447, [durban@rehau.com](mailto:durban@rehau.com) Johannesburg, +27 11 2011300, [johannesburg@rehau.com](mailto:johannesburg@rehau.com) Cape Town, +27 21 9821254, [capetown@rehau.com](mailto:capetown@rehau.com) East London, +27 43 7095400, [eastlondon@rehau.com](mailto:eastlondon@rehau.com) If there is no sales office in your country, +49 9131 925888, [salesoffice.bd@rehau.com](mailto:salesoffice.bd@rehau.com)

© REHAU AG + Co  
Rheniumhaus  
95111 Rehau/Germany

M01671 EN 09.2018